


SPARE PARTS EXPLODED VIEW STORAGE ELECTRIC WATER HEATERS Model

EUREKA

R8215274-02EN - Edition 02 - 01/07/2010

410 634		DOCCIA EUREKA 1500/230		
410 631		DOCCIA EUREKA 2000/230		
Reference	Ind.	Model type	Begin	End



Key	N Description	Manf. Pt.	N Type		7	**/*/	/	nf. date	
2224	[from	/ to	
0001	ELEMENT 1830W 230V ELEMENT 2000W 230V	411381 816745		•	•		01/03	12/02	
0003	THERMOSTAT	410658		•	•			12/02	
0003	THERMOSTAT	411378		•	•		01/03	12/02	
0007	HEATING ELEMENT FIXING PLATE	410659		•	•		01/03		
	PLASTIC COVER	410746		•	•			08/02	
0014	PLASTIC COVER	410747		•	•		09/02	00/02	
0019	SIGNAL LAMP	410674		•	•		03/02		
	BIPOLAR SWITCH	410661		•	•				
	SAFETY VALVE	411379		•	•				
	NUT NYLON	411380		•	•				
	WALL BRACKET	410656		•	•				
	O RING (ELEMENT)	570118		•	•				
	FLANGE GASKET	410673		•	•				
	TANK	410828		•	•		06/02		
	CABLE CLAMP	573266		•	•		05/02		
	CABLE (POWER SUPPLY)	411265		•	•		00/02	09/02	
3000	CABLE (FOWER SUPPLY)	65103453		•	•		10/02	55,52	
0056	RIDUCTOR	411251		•	•		06/02	06/04	
3000	RIDUCTOR	65103191		•	•		07/04	03/04	
0057	CERAMIC DISC CARTRIDGE	411374		•	•		07704		
	TAP BODY	411373		•	•				
	SINK FLUE	410738		•	•				
	THERMOFUSIBLE	410738						12/02	
	SWITCHING PLATE			•	•			12/02	
		410662			•				
	HANDLE UNIT	410666		•	•				
	NUT M 105	410667		•	•				
0085	NUT M 38X1.5	410670		•	•				
								1	
								1	
								1	
						, I			

LIST OF THE ABBREVATIONS

HW : Hot water. CW : Cold water. : Ceramic resistance (normal heating). : Ceramic resistance (accelerated heating) TP : Immersion heater. 1F : With fittings. 2F : Without fittings. 3F With fittings and another outlet connection. AMI : With mixing valve. SMI : Without mixing valve. PUISS : Power of th appliance. PN : Appliance with normal pression. LP : Appliance with low pression. PV : Appliance with variable power. : Appliance with fixed power..

IDENTIFICATION PLATE

SERIAL NUMBER

